


General Safety Information



3. Use a blunt instrument to fit the tab on the other end of the reflector in at (\underline{B}) on the pedal.




4. Turn the adjustment bolt on the pedal to adjust the spring tension to the strongest setting.




Removal


1. Turn the adjustment bolt on the pedal to adjust the spring tension to the weakest setting.

PD-M970: 2.5 mm Allen key PD-M959/PD-M770/PD-M540/ PD-M520/PD-M515/PD-M505: 3 mm Allen key





2. Use a blunt instrument to pry the reflector tab out from $\ensuremath{\mathbb{B}}$ in the pedal.



Please note: Specifications are subject to change for improvement without notice. (English)

SHIMANO

SHIMANO AMERICAN CORPORATION One Holland, Irvine, California 92618, U.S.A. Phone: +1-949-951-5003 SHIMANO EUROPE B.V. Industrieweg 24, 8071 CT Nunspeet, The Netherlands Phone: +31-341-272222 SHIMANO INC. 3-77 Oimatsu-cho, Sakai-ku, Sakai, Osaka 590-8577, Japan

© Dec. 2006 by Shimano Inc. PIT. IZM. Printed in Malaysia

Note:

SM-PD22

 This reflector (SM-PD22) is for use with the PD-M970/ PD-M959/PD-M770/PD-M540/PD-M520/PD-M515/PD-M505 pedals only.


Reflector

• The reflector can be installed on either a left or right pedal.

Technical Service Instructions

Installation

1. Turn the adjustment bolt on the pedal to adjust the spring tension to



2. Press the reflector tab firmly in at A on the pedal.

